

LARIAC4: Image Capture and Aerotriangulation

Katie Neal-Vacca
Project Manager – Photogrammetric Products
Presented February 6th, 2014

Agenda

Project Team Outline

Adjustments in Capture

- With more experience: Oblique Centric to Full Project
- Plane Allocation

Updated Sensor

- 16MP to 29MP
- Decrease in required AT Blocks

Ground Control

Updates in procedure to avoid future delays

Current Capture Status & Schedule

Aero-Triangulation description




LARIAC4 Project Team


- Pictometry:
 - Aerial (ortho and oblique) and LiDAR Capture
 - Acquiring Ground Control
 - Aero-Triangulation
 - Training & Support
- Sanborn
 - Ortho Rectification and Correction
 - Building Outline Updates
- Dewberry
 - QC of AT
 - QC of Obliques
 - QC of Ortho Product



Adjustments in Capture: 2011 vs 2014




Updated Sensor – 29 blocks to 16 blocks






Updated Sensor: Cause and Effect on AT



Control: Updated Procedure





Flight Schedule


LAR-IAC Imagery Acquisition Schedule														
	AT Bloc	Total Hours	Block Start	Block Finish**	4-Jan	11-Jan	376	25-Jan	Veek i 1-Feb	Ending	15-Feb	****	1-Mar	8-Mar
North	21, 22	30	11-Jan	1-Feb	30	30	7 23	2 14	14					
	23, 24	18	28-Dec	18-Jan	1 11	1 7	7		68 6					
	25, 26	18	28-Dec	11-Jan	2 14	2 14								
	17, 18	24	11-Jan	8-Feb	24	24	1 17	1 7	1 3	8				
	19, 20	22	28-Dec	25-Jan	1 15	1 8	7	7		-				
Ş.	L, 15, 1	43	28-Dec	8-Feb	7 36	29	7 22	1 15	1 8	1				
South	12, 13	23	28-Dec	11-Jan	2 14	2 14								
	10, 11	31	11-Jan	8-Mar	31	31	7 24	1 17	1 10	8 2	9			
	8, 9	39	25-Jan	15-Feb	39	39	39	7 32	7 25	8 17	18			
	4, 5	39	28-Dec	18-Jan	2 14	2 14	14							
	6, 7	18	11-Jan	1-Feb	18	18	7 11	7 4	7					
	2, 3	20	1-Feb	15-Feb	20	20	20	20	20	8 13	18			
	1	17	1-Feb	15-Feb	17	17	17	17	17	8 9	9			
IIIBI	27	22	28-Dec	25-Feb	1 15	7 8	7	7						
Foreston	28	23	1-Feb	1-Mar	23	23	23	23	23	23	23	18	9	
	29	46	1-Feb	8-Mar	46	46	46	46	46	46	46	2 18	18	2 18
ğ	N/A	130	28-Dec	18-Jan	130	130	130	2 14	3 21	3 21	3 21	3 21	3 11	14
	Comple	te		behind schedule		finished at	nead of sch	edule					0-9	




Updated Schedule

Orthogonal Imagery Details and Schedule By Block										
AT Block(s)	Est. Total Ortho Frame Count	AT Start*	RFP AT Block Completion*	Updated AT Completion*	Ortho Delivery*					
23, 24	13,063	25-Jan	8-Mar	8-Mar	6-Jun					
25, 26	13,250	18-Jan	8-Mar	26-Mar	24-Jun					
12, 13	16,076	18-Jan	8-Mar	8-Mar	6-Jun					
19, 20	14,500	1-Feb	13-Mar	22-Mar	20-Jun					
4, 5	14,324	25-Jan	13-Mar	13-Mar	11-Jun					
27	7,200	8-Feb	13-Mar	13-Mar	22-May					
21,22	14,630	8-Feb	22-Mar	30-Mar	20-Jun					
17, 18	13,361	15-Feb	26-Mar	8-Mar	6-Jun					
14, 15, 16	20,151	15-Feb	30-Mar	13-Mar	11-Jun					
10, 11	14,641	15-Mar	8-Apr	8-Apr	7-Jul					
1	5,902	22-Feb	8-Apr	8-Apr	17-Jun					
8, 9	14,365	22-Feb	15-Apr	15-Арг	14-Jul					
6, 7	9,943	8-Feb	15-Apr	15-Apr	24-Jun					
2, 3	11,192	22-Feb	15-Apr	15-Арг	14-Jul					
28	5,089	10-Apr	15-May	15-May	24-Jul					
29	10,206	10-Apr	15-May	15-May	30-Jul					
*Estimate										










Used to improved image alignment

Tie Points between images generated automatically to improve *relative* accuracy

- Many automatic points are features not easily identified by the human eye
- 100-200 or more points per image


Surveyed Control Points are manually measured in imagery to improve *absolute* positional accuracy





The purpose of AT is to recompute the camera centers in order to get the best possible alignment of features (tie points) between images as well as with the measured ground control points.





The purpose of AT is to recompute the camera centers in order to get the best possible alignment of features (tie points) between images as well as with the measured ground control points.



Bundle Adjustment

Bundle adjustment is run to adjust final exterior orientation parameters (X, Y, Z, Roll, Pitch, Yaw) to minimize errors between frames

- Improves relative alignment
- With ground control, improves and verifies absolute accuracy!




Reporting

Total of 2411744 measurements in 10305 photos are used for adjustment (total 10305 photos)

```
1.6 micron (18:08:18)
sigma naught
sigma naught
                1.6 micron (18:11:52)
found
        45836 points connecting 2 photos
found
       253615 points connecting 3 photos
found
        67080 points connecting 4 photos
        79354 points connecting 5 photos
found
found
        82942 points connecting 6 photos
        21626 points connecting 7 photos
found
found
        15504 points connecting 8 photos
found
        7036 points connecting 9 photos
found
         3498 points connecting 10 photos
found
        1311 points connecting 11 photos
found
         253 points connecting 12 photos
found
         17 points connecting 13 photos
number of observations
                                4875218
number of unknowns
                                1796064
redundancy
                                3079154
RMS automatic points in photo (number: 2406481)
                                                                                 x=1.3 micron
                                                                                                                  y=1.3 micron,
RMS control and manual points in photo (number: 174)
                                                                                 x=3.8 micron
                                                                                                                  y=3.6 micron
RMS control points with default standard deviation set (number: 26)
                                                                                                  z=0.009 [feet]
                                                 x = 0.090 [feet] y = 0.106 [feet]
RMS IMU observations (number: 10305)
                                                 omega=0.009 [deg]
                                                                                 phi=0.009 [deg] kappa=0.016 [deg]
RMS GNSS observations (number: 10305)
                                                 x=0.220 [feet]
                                                                                 y=0.262 [feet]
                                                                                                                  z= 0.416 [feet]
```



Refined EOs



- Refined EOs used for Certified Ortho
 Product
- Imagery now accurate to < 1m
- Inter-frame alignment < 3 pixels





Thank you! Questions?